


PUTTING UP THE GATE



**1.** Push in both hinge pins and fully open gate until you hear a click



**4.** Expand bottom telescope so both pads fit snug on either side of the opening

**5.** Depress the ratchet 2x to hold bottom telescope in place



**2.** Stand up gate with logo facing away from you. Place gate in opening and expand top telescope so both pads fit snug on either side of the opening



**6.** Repeat ratcheting on top and bottom 2 or 3 times more to make sure gate is secure

**7.** Move the locking plate into the locked position on top and bottom



**3.** Depress the ratchet 2x to hold top telescope in place

TAKING DOWN THE GATE




**1.** Move the locking plate into the unlocked position on top and bottom



**3.** Lay gate on the floor, while pressing bottom unlock button slide the telescope back to the original position



**2.** While pressing the unlock button (**be sure to not depress ratchet on opposite side**), slide the top telescope back to the original position



**4.** Flip gate over with navigate logos facing up. Push in hinge pins to fold back to original position